

ALPINERX



QUICK START



01.

Download the ALPINERX APP for iOS or Android



Download on the App Store

GET IT ON Google Play

02.

Activate Bluetooth on your phone

03.

Follow the instructions within the app to pair your watch and set your goals



ALPINERX APP

Compatible with iOS & Android



Download on the App Store



GET IT ON Google Play


Alpina

1883 GENEVE

MORE INFORMATION
alpinawatches.com



ALPINERX

REACH YOUR SUMMIT

QUICK START




Alpina

1883 GENEVE



QUICK START

THANK YOU
FOR PURCHASING
YOUR ALPINERX
AND BECOMING
A MEMBER OF THE
ALPINA COMMUNITY!
PLEASE FOLLOW
THE SIMPLE STEPS
DETAILED IN THIS
QUICK START GUIDE
TO START USING
YOUR WATCH.

ALPINERX  QUICK START

PAIR YOUR WATCH

To pair your watch, launch the ALPINERX application and press on press "I'VE GOT AN ALPINERX". Place your ALPINERX close to your phone. Push the watch's crown button and then press on the "start" button appearing on your app screen. Once your ALPINERX has been found, briefly press and release the crown again to pair. Press on "next" and follow the instructions.



ALPINERX  QUICK START

FUNCTIONS & FEATURES

